

Working procedure



Before



Remove existing galvanize coating paint by paint removal.



Stop rust expansion by rust expansion solution.



Apply DurAlloy on defect area.



Apply DuraWrap primer for on prepared area.



Apply Carbon fiber fabric onto the DuraWrap primer layer.



During spiral carbon fiber fabric apply DuraWrap polymer thoroughly on carbon fiber surface.



Complete