METALCLAD



The super fast leak stopper!

- Ultra Fast Curing
- Trowelable
- Requires No Heat
- Unlimited Shelf Life
- 100% Solids
- Safe & Simple To Use

METALCLAD® SpeedAlloy[®] QS is a two component, 100% solids, high performance polymer composite that can be used to assist in making effective repairs to all types of pipes, tanks and equipment which must be returned to service very quickly or where shut downs are not possible.

METALCLAD® SpeedAlloy[®] QS has an extremely fast initial set time, making it the ideal material for stopping the flow and effectively plugging almost any active leak - allowing time for proper surface preparation and the application of ENECON[®]'s standard METALCLAD[®] SpeedAlloy[®] or METALCLAD[®] DurAlloy[®] (over the SpeedAlloy[®] QS) to create a long-term repair.



Repairs...

- Sumps
- Radiators & Fuel Tanks
- Cracked & Holed Casings
- Seams
- ...and more







Corporation The Fluid Flow Systems Specialists.

Toll Free: 888-4-ENECON (888-436-3266) Tel: 516 349 0022 · Fax: 516 349 5522 info@enecon.com 6 Platinum Court · Medford, NY 11763-2251

Technical Data

Volume capacity per 250 gm unit.		10.5 in ³ / 172 cc			
Mixed density		0.052 lbs per in ³ / 1.45 gm per cc			
Coverage rate per 250 gm unit					
@ 0.25 in / 6 mm		42 in ² / 0.027 m ²			
Shelf life		Indefinite			
Volume solids		100%			
Mixing ratio	Base	Activator			
By volume	1	1			
By weight	1	1			

Work	ing Life	& Cure T	imes	
Amb	pient	Working	Light	Full
Tempe	erature	Life	Load	Mechanical
41°F	5°C	5 min	30 min	2 hrs
59°F	15°C	2 min	10 min	1 hrs
77°F	25°C	1 min	5 min	40 min
86°F	30°C	45 sec	3 min	30 min

Physical Proper	Test Method				
Compressive strength	11,000 psi	770 kg/cm ²	ASTM D-695		
Hardness - Shore D	80		ASTM D-2240		
Tensile Shear Adhesion					
Steel	2100 psi	147 kg/cm ²	ASTM D-1002		
Aluminum	1900 psi	133 kg/cm ²	ASTM D-1002		
Copper	1800 psi	126 kg/cm ²	ASTM D-1002		
Stainless steel	2000 psi	140 kg/cm ²	ASTM D-1002		

SpeedAlloy[®] QS has an extremely fast initial set time, making it the ideal material for stopping the flow and effectively plugging virtually any leak. The use of the SpeedAlloy[®] QS, therefore, allows time for proper surface preparation and application of either standard SpeedAlloy[®] or DurAlloy[®] (over the SpeedAlloy[®] QS) for a long-term repair.



Printed in the USA October, 2014

Using SpeedAlloy[®] QS

Surface Preparation - METALCLAD[®] SpeedAlloy[®] QS should be applied to clean, dry and well roughened surfaces for maximum adhesion. Under field conditions, perform the following steps as best as conditions permit. The better the surface preparation, the better the adhesion. 1. Remove all loose material and surface contamination and clean with a suitable solvent which leaves no residue on the surface after evaporation such as acetone, MEK, isopropyl alcohol, etc.

2. If necessary, apply moderate heat to remove ingrained oil and clean again with solvent.

3. Roughen surface by abrasive blasting, grinding, rotary file or other appropriate means.

Mixing & Application - For your convenience, the METALCLAD[®] SpeedAlloy[®] QS Base and Activator have been supplied in precisely measured quantities to simplify mixing of full units. Should a small amount of material be required, measure out one part Base and one part Activator by volume (1:1, v:v) on a clean mixing surface. Keep Base and Activator separated until ready to mix and apply.

THIS IS AN EXTREMELY FAST SETTING SYSTEM. SPEEDALLOY™ QS MUST BE MIXED AND APPLIED WITHIN 1 MINUTE.

Using a spatula, putty knife or other appropriate tool, mix thoroughly until all streaks disappear, resulting in a uniform color and consistency. Apply to the area to be plugged or repaired as quickly as possible (within 1 minute) firmly pressing the material well into the repair area and holding in place until the leak is stopped. Once the leak is stopped, a long-term repair can be made using standard SpeedAlloy[®] or DurAlloy[®] over the SpeedAlloy[®] QS

Health& Safety - Every effort is made to insure that ENECON[®] products are as simple and safe to use as possible. Normal industry standards and practices for housekeeping, cleanliness and personal protection.

Cleaning Equipment - Wipe excess material from tools immediately. Use acetone, MEK, isopropyl alcohol or similar solvent as needed.

Technical Support - The ENECON[®] engineering team is always available to provide technical support and assistance. For guidance on difficult application procedures or for answers to simple questions, call your local ENECON[®] Fluid Flow Systems Specialist or the ENECON[®] Engineering Center.



All information contained herein is based on long term testing in our laboratories as well as practical field experience and is believed to be reliable and accurate. No condition or warranty is given covering the results from use of our products in any particular case, whether the purpose is disclosed or not, and we cannot accept liability if the desired results are not obtained.

Copyright © 2014 by ENECON[®] Corporation. All rights reserved. No part of this work may be reproduced or used in any form or by any means - graphic, electronic or mechanical including photocopying, recording, taping or information storage and retrieval systems without written permission of ENECON[®] Corporation.