ENECRETE[®] DuraQuartz[®] LW

Extraordinary light weight concrete repair and rebuilding system for vertical and overhead surfaces.

ENECRETE® DuraQuartz® LW is a three component, 100% solids, concrete repair compound specifically formulated and precisely engineered to provide solutions to even the most difficult verticle and overhead concrete repair and protection problems.

ENECRETE DuraQuartz LW is extremely versatile. It can be mixed to any consistency - from a viscous liquid to a stiff mortar. DuraQuartz LW is not only for concrete; it will bond to marble, stone, slate, terrazzo, tiles and even metal.







- Outstanding Compressive Strength
- 100% Solids
- Safe & Simple
 To Use

Bonds to...

- Concrete
- Marble
- Stone
- Slate
- Terrazzo
- Tiles
- Metal
- · Wood





Toll Free: 888-4-ENECON (888-436-3266)

Tel: 516 349 0022 · Fax: 516 349 5522

info@enecon.com

6 Platinum Court · Medford, NY 11763-2251

Technical Data				
Volume capacity per 5 kg		400 in ³ / 6550 cc		
Mixed density		0.027 lbs per in ³ / 0.74 gm per cc		
Coverage rate per 5 kg @ 0.25 in / 6mm		12 ft² / 1.1 m²		
Shelf life		Indefinite		
Volume solids		100%		
Mixing ratio	Base	Activator		
By volume	5	2		
By weight	2.4	1		

Worki	ing Life	& Cure	Times		
	oient erature	Working Life	Light Load	Full Mechanical	Chemical Immersion
41°F	5°C	3 hrs	3 days	7 days	10 days
59°F	15°C	90 min	6 hrs	36 hrs	7 days
77°F	25°C	60 min	4 hrs	24 hrs	4 days
86°F	30°C	30 min	3 hrs	16 hrs	3 days

es Typic	cal Values	Test Method
5,000 psi	350 kg/cm ²	ASTM C-109
57		ASTM D-2240
	5,000 psi	5,000 psi 350 kg/cm ²

Elcometer adhesion - to cementitious and mineral type substrates is generally greater than the cohesive strength of such materials.

Chemical Resistance			
Acetic acid (0-5%) EX Acetone G Ammonia solution (0-10%) EX Aviation fuel EX Butyl alcohol G Calcium chloride EX Crude oil EX Diesel fuel EX Ethyl alcohol G Gasoline EX Heptane EX Hydrochloric acid (0-10%) EX Hydrochloric acid (10-20%) G Kerosene EX Lactic acid (0-10%) G EX - Suitable for most application of the control of the	Methyl alcohol G Methyl ethyl ketone G Nitric acid (0-10%) G Palmitic acid EX Phosphoric acid (0-5%) EX Phosphoric acid (5-10%) G Potassium chloride EX Propyl alcohol G Sodium chloride EX Sodium hydroxide EX Sulfuric acid (0-50%) G Tannic acid EX Toluene G Transformer oil EX Xylene EX tions including immersion.		



Using DuraQuartz®LW

Surface Preparation - ENECRETE® DuraQuartz® LW should only be applied to clean, dry, firm and well roughened surfaces.

- 1. Remove all loose material and surface contamination.
- Depending on the surface, solvent clean and/or remove contamination by abrasive blasting, steam cleaning, pressure washing, or other suitable means.
- 3. After removing all surface and sub-surface contamination, flush the area as necessary and allow to dry completely.

Priming The Surface - ENECRETE® DuraQuartz® Primer is supplied in each DuraQuartz® LW system. Pour the contents of the Primer Activator container into the Primer Base container and mix thoroughly. Apply the mixed Primer to the area to be coated with DuraQuartz® LW using a brush or a roller. Use only enough Primer to "wet" the surface; do not flood or pool the Primer. All the Primer should be used within 20 minutes of mixing. Overcoating with DuraQuartz® LW should begin immediately after Priming and should be completed within two hours.

Mixing & Application - For your convenience, the ENECRETE® DuraQuartz® LW Base, Activator and Aggregate have been supplied in precisely measured quantities to simplify mixing of full units. Should a small amount of material be required, measure out 5 parts Base and 2 parts Activator by volume (5:2, v/v) and add Aggregate until the desired consistency is achieved.

To facilitate mixing of full units, a mechanical mixing device is strongly recommended. Combine the Base and Activator liquids in the large, plastic bucket and, with the mixer running, slowly add the Aggregate. Using all the Aggregate will yield a stiff, mortar-like paste; less Aggregate will result in a viscous fluid consistency.

Apply the mixed DuraQuartz®LW to the prepared and Primed surface using a trowel, putty knife, or other appropriate tool, pressing well to insure intimate contact and force out any air entrapped as a result of the mixing technique and/or device

Cleaning Equipment - Wipe excess material from tools immediately. Use acetone, MEK, isopropyl alcohol or similar solvent as needed.

Health & Safety - Every effort is made to ensure that ENECON® products are as simple and safe to use as possible. Normal industry standards and practices for housekeeping, cleanliness and personal protection should be observed. Please refer to the detailed SAFETY DATA SHEETS (SDS) supplied with the material (also available on request) for more information.

Technical Support - The ENECON® engineering team is always available to provide technical support and assistance. For guidance on difficult application procedures or for answers to simple questions, call your local ENECON® Fluid Flow Systems Specialist or the ENECON® Engineering Center.



All information contained herein is based on long term testing in our laboratories as well as practical field experience and is believed to be reliable and accurate. No condition or warranty is given covering the results from use of our products in any particular case, whether the purpose is disclosed or not, and we cannot accept liability if the desired results are not obtained.

Copyright © 2015 by ENECON® Corporation. All rights reserved. No part of this work may be reproduced or used in any form or by any means - graphic, electronic or mechanical including photocopying, recording, taping or information storage and retrieval systems - without written permission of ENECON® Corporation.